	TE-PUFPLUS Hi-Vol PAH Air Sample Data Form
Sample Information	Full Site Name: BUNNS harbor - Port of Indians
Sample Informa	Site Abbreviation BHP Deployment No
Field Deployment and Recovery	Field Deployment Technician Name See To Keller Setup Date/Time 7/22/21/13/40 Sample Run Date 7/2 3/2 Flow Conditions should be STD. Flow Rate should be 225 liters/min. Once all necessary fields in Timer screen have been set, 3 things should happen: Begreen power light should start to blink; Timer countdown should start indicating when sampling run will commence; Status on main screen should change to "Waiting". Field Recovery Technician Name Recovery Date/Time 11.11 7/26/2 Qstd Avg Flow (liters/min) 2 7 Actual Start Date/Time 7/23/2 7/23/2 Qstd Volume (m³) 1/4 1/1 Tamb Avg (°C) 24.5 Elapsed Time (HH:MM) 9 1/2 1/3 Pamb Avg (mmHg) 9/4 Flags? Expected flags: Completed, Ostd FLOO (Circle one) VOID Reason: FLOO RAVE (INSULTION) FROM Day Precipitation: 0 0 Run Day Precipitation: 0 0 Run Day Wind/Wind Direction: 12 MPH Run Day Sky Cover: PAKILY CLAMP! Unusual Events? (fires, major storms, construction, etc.):
Maintenance	Weekly Checks: Monthly Checks: (after 5th sample run of the month) □ Power cords/plugs ok? □ Sampling head cleaned with Kim wipes? □ Gaskets ok? □ Pictures of site logbook taken? □ Shelter ok? □ Completed TE-PUFPLUS One-Point Flow Check Form? □ Tubing ok? □ Temperature sensors within ±2°C of transfer standard? □ Timer ok? □ Pressure sensor within ±10 mmHg of transfer standard? □ Debris removed? □ One-point flow verification within ±10% of Qstd PUFPLUS (0.225 min)? Maintenance Notes: